

Installation Instructions for

KÜÜL® PADS 2" Pad Hanger



- 1** Seat the top, inside of the hanger against the top of the cooling pad.
- 2** Level the hanger and press toward the center of the 12" cooling pad.
- 3** Two hangers are recommended for 24" wide pads. Hangers should be installed six inches from outside top corners.

NOTE: Pad Hangers should be used in conjunction with bottom pad troughs.